



VENTUS G.102 GPS-TRACKER

-QUICK START GUIDE-

1. What you need:
 - GPS-tracker
 - GSM SIM card (ex. cash card)
 - Mobilephone with SIM card
 - PC with Google Earth installed
2. Please charge the GPS tracker battery for at least 12 hours by using one of the included chargers.
3. Insert the new GSM SIM cash card in a mobilephone (which must be SIM unlocked) and do the following:
 - When you have activated the SIM cash card according to the description that was along with the SIM cash card, please go to the set up in the mobile phone and turn off pin code and voicemail.
4. Please take the GSM SIM cash card out of the mobilephone and insert to the GPS tracker.
5. Insert the battery, that has been charged for at least 12 hours, in the GPS tracker.
6. Go outside under open sky and turn on the GPS tracker. Please check that it is flashing every 4th second.
7. Use your mobilephone with your normal SIM card and send the following text message (SMS) to the GPS tracker: begin123456
8. After awhile will you receive a text message (SMS) saying: begin ok.
9. Call now the GPS tracker from your mobile phone. The GPS tracker will hang up and you a text message (SMS) with latitude and longitude, speed and power
10. Go to Google Earth which must be installed on your PC. If not please go to www.google.com and write google earth and download Google Earth. Insert (in upper left corner search box), latitude coordinate and then longitude coordinate. The two coordinates must only be separated by a comma. (Remember if there is a dot or a letter in the coordinate, this must be inserted too.) You will now see on Google earth where your GPS tracker are.